

ELKO EP, s.r.o.

Palackého 493 769 01 Holešov, Všetuly Czech Republic Tel.: +420 573 514 211 e-mail: elko@elkoep.com www.elkoep.com

Made in Czech Republic 02-51/2023



HRN-43 HRN-43N

Voltage monitoring relay for complete control in 3P incl. asymmetry




Characteristics

- · Relay is designed to monitor voltage in 3-phase networks:
 - HRN-43: delta connection 3× 400 V (without neutral)
 - HRN-43N: star connection 3×400/230 V (with neutral)
- Monitors level of voltage in two independent levels (Umax, Umin) overvoltage and undervoltage: system 3× 400 V: range 240 – 480 V system 3× 400/230 V: range 138 – 276 V
- Other monitored parameters:
 - phase failure, sequence, asymmetry (adjustable, can be switched off)
- Setting the monitored lower level (Umin) in % of the set upper level Umax.
- Adjustable time delay (eliminanting short-term drops and spikes).
- Selectable function of output contacts (independently/in parallel).
- · Output contact for each monitored voltage level.


Description

HRN-43N





- . Supply voltage terminals (A1-A2)
- 2. Supply voltage indication
- 3. Overvoltage/undervoltage, phase failure indication
- 4. Phase sequence indication
- 5. Phase asymmetry indication
- 6. Voltage monitoring terminals (N-L1-L2-L3)
- 7. Phase asymmetry monitoring (YES/NO)
- 8. Memory function
- 9. Output function setting
- 10. Hysteresis setting
- 11. Time delay Umax/Umin
- 12. Upper level setting (Umax)
- 13. Memory reset
- 14. Asymmetry setting
- 15. Lower level setting (Umin)
- 16. Output contact 2 (28-25-26)
- 17. Output contact 1 (16-15-18)

Connection



Symbol





Technical parameters

Supply		HRN-43	HRN-43N	
Supply terminals:		A1-A2		
Supply voltage:	Z	AC/DC 24 – 240 V (AC 50-60 Hz)		
Consumption (max.):		3 VA/1 W		
Supply voltage:	400V	AC 400 V	(50-60 Hz)	
Consumption (max.):	40	5 VA	/2.5 W	
Supply voltage tolerance:		-15 %	15 %; +10 %	

Measuring circuit

Monitored terminals:	L1-L2-L3	L1-L2-L3-N		
Voltage system:	3× 400 V (50-60 Hz)	3×400 V/230 V (50-60 Hz)		
Upper level setting (Umax):	240 – 480 V	138 – 276 V		
Lower level setting (Umin):	35 – 99 %Umax			
Max. permanent voltage:	3× 480 V			
Asymmetry:	adjustable, 5 – 20 % + OFF			
Peak overload (1 s):	600 V	350 V		
Time delay (t1):	fixed, max. 200 ms			
Time delay Umax/Umin (t2):	adjustable, 0.1 – 10 s			

Accuracy

Setting accuracy (mech.):	5 %
Repeat accuracy:	< 1 %
Temperature dependance:	< 0.1 %/°C (°F)
Limit values tolerance:	5 %
Hysteresis (fault to OK):	selectable, 5 %/10 % from the upper range value


Output


Contact type:	2× changeover/SPDT (AgNi)			
Current rating:	16 A/AC1			
Breaking capacity:	4000 VA/AC1, 384 W/DC1			
Inrush current:	30 A/< 3 s			
Switching voltage:	250 V AC/24 V DC			
Power dissipation (max.):	2.4 W			
Mechanical life:	10.000.000 ops.			
Electrical life (AC1):	100.000 ops.			


Other information

Other information	
Operating temperature:	−20 55 °C (−4 131 °F)
Storage temperature:	−30 70 °C (−22 158 °F)
Dielectric strength:	
supply – output	AC 4 kV
output 1 – output 2	AC 4 kV
Operating position:	any
Mounting:	DIN rail EN 60715
Protection degree:	IP40 front panel / IP20 terminals
Overvoltage category:	III.
Pollution degree:	2
Cross-wire section – solid/	max. 1× 2.5, 2× 1.5/
stranded with ferrule (mm2):	max. 1× 2.5 (AWG 14)
Dimensions:	90 × 52 × 65 mm (3.5" × 2" × 2.6")
Weight:	UNI – 148 g (5.2 oz), 400V – 248 g (8.7 oz)
Standards:	EN 60255-1, EN 60255-26, EN 60255-27

Function







Warning

This device is constructed for connection in 3-phase network AC $3\times$ 400 V or AC $3\times$ 400/230 V (according to the type) and must be installed according to norms valid in the state of an application. Installation, connection, setting and servicing must be carried out by qualified electrician staff only, which have perfectly understood the instructions and functions of the device. This device contains protection against overvoltage peaks and disturbing impulses in the power supply network. For the correct function of the protection of this device, there must be suitable protections of higher degrees (A,B,C) installed in front of them and according to the standards, interference of switching devices must be securely eliminated (contactors, motors, inductive loads, etc.). Before installation, make sure that the device is de-energized and the main switch is in the "OFF" position. Don't install the device to sources of excessive electromagnetic interference. Ensure correct installation by perfect air circulation so that during continuous operation and a higher ambient temperature, the device does not exceed the maximum allowed operating temperature. For installation and setting use a screwdriver with a width of approx 2 mm. Keep in mind that this is a fully electronic device and approach accordingly with the installation. Non-problematic function of the device is also dependent on the previous method of transportation, storage, and handling. In case of any signs of damage, deformation, malfunction, or missing parts, don't install this device and claim it at the dealer. The product must be treated as electronic waste at the end of its life.

Function of output contacts:

In order to monitor two levels of voltage, it is possible to select if output contact will respond to each level individually (see the diagram) or both contacts will switch in parallel (see diagram "phase sequence").

Selection via DIP switch "Output".

Graphs legend:

L1, L2, L3 = 3-phase voltage

RESET = memory reset t1 = time delay, fixed

t2 = time delay Umax/Umin, adjustable

15-18 = output contact 1 25-28 = output contact 2

LED ≥ U = overvoltage/undervoltage indication

Function of output contacts:

The function is not applicable in the phase sequence monitoring, the contacts are switched in parallel.

DIP switch "Output" is ignored.

Graphs legend:

L1, L2, L3 = 3-phase voltage RESET = memory reset

t1 = time delay, fixed

t2 = time delay Umax/Umin, adjustable

15-18 = output contact 1

25-28 = output contact 2

LED \triangle = phase sequence indication

Function of output contacts:

The function is not applicable in the phase asymmetry and failure monitoring, the contacts are switched in parallel way. DIP switch "Output" is ignored.

Graphs legend:

L1, L2, L3 = 3-phase voltage

RESET = memory reset

t1 = time delay, fixed

t2 = time delay Umax/Umin, adjustable A - adjustable asymmetry level

15-18 = output contact 1 25-28 = output contact 2

LED A = asymmetry indication

Relay is designated to monitor 3-phase circuits. Type HRN-43 controls the interphase voltage, type HRN-43N controls voltage towards the neutral wire. Relay can monitor: voltage in two levels (overvoltage/undervoltage), phase sequence/failure and asymmetry. Each fault state is indicated by an individual LED. By DIP switch "Output" it is possible to select the function of output contacts: independent function (1× for overvoltage, 1× for undervoltage) or in parallel. Fixed time delay (t1) is applied when changing from fault to OK state or when de-energized. Adjustable time delay (t2) is applied, when changing from OK to fault state. This delay prevents incorrect behavior and oscillation of the output device during short-term voltage drops and peaks.

Voltage monitoring

The upper level Umax is set in the range 138 - 276 V (resp. 240 - 480 V for HRN-43) and the lower level Umin in the range of 35 - 99 %Umax. In case any phase deviates from this set band, after a set delay, output contact opens. Output contact again closes after returning back into the monitored band and exceeding fixed hysteresis (selectable by DIP switch "Hysteresis"). In the event of an outage in two or three phases, the output contacts will open immediately, regardless of the set delay t2.

Phase sequence

Monitors correctness of phase sequence. In case of unwanted change, output contacts open. In case of energization of a relay with incorrect phase sequence, contacts stay open.

Asymmetry

The level of asymmetry between individual phases is set in the range of 5 - 20 %. In case set asymmetry is exceeded, output contacts open and LED indicating asymmetry shines. Time delays t1, t2 and hysteresis are applied when returning to OK state. Monitoring asymmetry can be switched off by the DIP switch "ASYM".

Type of load	 cos φ ≥ 0.95 AC1	-(M)- AC2	—(M)— AC3	=()= AC5a uncompensated	TITE IZE AC5a compensated	HAL.230V CAC5b	AC6a	 AC7b	— <u> </u>
Contact material AgNi, 16A	250V / 16A	250V / 5A	250V / 3A	230V / 3A (690VA)	х	800W	х	250V / 3A	250V / 10A
Type of load	<u>∃</u> €₩		 	———— DC1	—(M)—	—(M)—	———— DC12		 DC14
Contact material AgNi, 16A	250V / 6A	250V / 6A	250V / 6A	24V / 16A	24V / 6A	24V / 4A	24V / 16A	24V / 2A	24V / 2A